# Paths of analysis\*

# Synthia

October 10, 2022

# 1 Analysis parameters

Analysis type: Automatic Retrosynthesis

Rules: none selected

Filters: Exclude Diastereoselective reactions, Tunnels, FGI, FGI with protec-

tions

Max. paths returned: 50

Max. iterations: 2000

Commercial:

1. Max. molecular weight - 1000 g/mol

2. Max. price - 1500 \$/g

#### Published:

- 1. Max. molecular weight 1000 g/mol
- 2. Popularity 5

#### My Stockroom:

1. Max. molecular weight - 1000 g/mol

**Reaction scoring formula:** TUNNEL\_COEF\*FGI\_COEF\*STEP\*20+1000 000\*(CONFLICT+NON SELECTIVITY+FILTERS+PROTECT)

Chemical scoring formula: SMALLER^ 3,SMALLER^ 1.5

Min. search width: 400

Max. reactions per product: 60

<sup>\*</sup>The results stated herein were generated using the proprietary platform owned and maintained by Grzybowski Scientific Inventions, Inc., a subsidiary of Merck KGaA, Darmstadt Germany. The results are provided on an as is basis, and shall be used solely in connection with the rights afforded in the license agreement and for no other purpose.

Strategies: none selected

FGI Coeff: 0

Tunnels Coeff: 0

JSON Parameters: {}

# 2 Paths

2 paths found. Paths are sorted by score. Reactions are sorted in appearance order for each path.

#### 2.1 Path 1

Score: 259.51




Figure 1: Outline of path 1

# 2.1.1 Huisgen Cycloaddition

# Substrates:

- $1. \ 5\text{-Hexyn-3-ol} \quad \textit{available at Sigma-Aldrich}$
- 2. 3-Azido-1-propanol available at Sigma-Aldrich

#### **Products:**

 $1. \ \mathrm{CCC}(\mathrm{O})\mathrm{Cc1cn}(\mathrm{CCCO})\mathrm{nn}1$ 

 $\textbf{Typical conditions:} \ \mathrm{Cu(I).H2O}$ 


Protections: none

**Reference:** 10.1039/PS9610000357 and 10.1016/S1359-6446(03)02933-7 and

10.1002/1521-3773 (20010601) 40:11 < 2004::AID-ANIE2004 > 3.0.CO; 2-5

Retrosynthesis ID: 10268

# 2.1.2 Appel Reaction



# ${\bf Substrates:}$

 $1. \ CCC(O)Cc1cn(CCCO)nn1 \\$ 

# Products:

1. CCC(O)Cc1cn(CCCCl)nn1

Typical conditions: PPh3.CCl4

Protections: none

**Reference:** 10.2174/1570179412666150305231358

# 2.1.3 Iodination of aromatic compounds

#### Substrates:

1. CCC(O)Cc1cn(CCCCl)nn1

# Products:

1. CCC(O)Cc1nnn(CCCCl)c1I

Typical conditions: I2 or other iodinating agent e.g. NIS

Protections: none

**Reference:** DOI: 10.1039/C5SC00964B and 10.1016/j.tetlet.2005.05.117 and

10.1007/s11178-005-0256-1

# 2.1.4 Deoxygenation of alcohols with silanes

# Substrates:

 $1. \ \mathrm{CCC}(\mathrm{O})\mathrm{Cc1nnn}(\mathrm{CCCCl})\mathrm{c1I}$ 

# **Products:**

1. CCCCc1nnn(CCCCl)c1I

 $\textbf{Typical conditions:} \ Et 3 Si H. Lewis. or. Bronsted. Acid$ 

Protections: none

**Reference:** 10.1021/jo0158534 AND 10.1021/ol3020144

#### 2.1.5 Heck Reaction

#### Substrates:

- 1. CCCCc1nnn(CCCCl)c1I
- 2. Cyclohexene available at Sigma-Aldrich

#### **Products:**

 $1. \ \ CCCCc1nnn(CCCCl)c1C1 = CCCCC1$ 

Typical conditions: Pd (cat). Ligand e.g. TXPTS. Base. Temp

Protections: none

**Reference:** 10.1016/j.tetlet.2013.01.077 or 10.1002/9780470716076 or 10.1021/op050106k or 10.1021/ol0360288 or 10.1021/ol702755g or 10.1055/s-0033-1340319 or 10.1016/j.tet.2004.10.049

# ${\bf 2.1.6}\quad {\bf Oxohydroxylation\ of\ unsymmetric\ alkenes}$

# Substrates:

1. CCCCc1nnn(CCCCl)c1C1=CCCCC1

# **Products:**


 $1. \ \ CCCCc1nnn(CCCCl)c1C1(O)CCCCC1 = O$ 

Typical conditions: KMnO4.Acetone/H2O.-10 deg C

Protections: none

**Reference:** 10.1016/j.tetlet.2015.12.042 and 10.1021/jacs.5b05792

# 2.1.7 Alkylation of tertiary alcohols



# Substrates:

 $1. \ \ CCCCc1nnn(CCCCl)c1C1(O)CCCCC1 = O$ 

# **Products:**

1. CCCCc1nnn2c1C1(CCCCC1=O)OCCC2


Typical conditions: K2CO3.acetone.heat

Protections: none

**Reference:** 10.1016/S0040-4020(01)90106-1 and 10.1021/acs.analchem.5b04461

and 10.3390/molecules 24091643

# 2.1.8 Shapiro reaction



#### Substrates:

 $1. \ \ CCCCc1nnn2c1C1(CCCCC1=O)OCCC2$ 

#### **Products:**

 $1. \ \ CCCCc1nnn2c1C1(C=CCCC1)OCCC2$ 

 $\textbf{Typical conditions:} \ 1.TsNH2NH2.2.N-BuLi$ 

Protections: none

**Reference:** 10.1021/jm4008517 and 10.1016/j.bmc.2009.08.038 and

10.1021/jo00350a003

Retrosynthesis ID: 9990398

# 2.2 Path 2

Score: 262.41





Figure 2: Outline of path 2

# 2.2.1 Deoxygenation of alcohols with silanes



# Substrates:

1. 1-chloro-3(1,2,3)triazol-1-ylpropan-2-ol

# **Products:**


1. C5H8ClN3

Typical conditions: Et3SiH.Lewis.or.Bronsted.Acid

 ${\bf Protections:}\ {\bf none}$ 

**Reference:** 10.1021/jo0158534 AND 10.1021/ol3020144

# 2.2.2 Chlorination of aromatic compounds



# Substrates:

1. C5H8ClN3

# Products:


1. ClCCCn1cc(Cl)nn1

Typical conditions: Cl2 or other chlorinating agent like NCS

Protections: none

**Reference:** DOI: 10.1007/s11178-005-0256-1

# 2.2.3 Iodination of aromatic compounds



#### Substrates:

1. ClCCCn1cc(Cl)nn1

#### **Products:**

1. ClCCCn1nnc(Cl)c1I

Typical conditions: I2 or other iodinating agent e.g. NIS

Protections: none

Reference: DOI: 10.1039/C5SC00964B and 10.1016/j.tetlet.2005.05.117 and

10.1007/s11178-005-0256-1

Retrosynthesis ID: 10697

# 2.2.4 Synthesis of aryl Grignard reagents



#### Substrates:

1. Magnesium - available at Sigma-Aldrich

2. ClCCCn1nnc(Cl)c1I

#### **Products:**

1. ClCCCn1nnc(Cl)c1[Mg]Br

Typical conditions: iPrMgCl.LiCl.THF or other conditions Mg.THF or

tBuLi.MgBr2


Protections: none

**Reference:** DOI: 10.1016/S0040-4039(99)01404-5 and 10.1021/jo0000574 and

WO2014123793 p.137 and 10.1021/jm400491x and 10.3762/bjoc.12.36

Retrosynthesis ID: 10011460

# 2.2.5 Grignard-Type Reaction



#### Substrates:

1. ClCCCn1nnc(Cl)c1[Mg]Br

2. 2-Cyclohexen-1-one - available at Sigma-Aldrich

#### **Products:**

 $1. \ OC1(c2c(Cl)nnn2CCCCl)C=CCCC1$ 

Typical conditions: Mg or Li.ether

Protections: none

**Reference:** 10.1021/jm061429p or 10.1016/j.bmc.2012.11.015 or

10.1016/j.tetasy.2012.05.024

# 2.2.6 Alkylation of tertiary alcohols

#### Substrates:

 $1. \ OC1(c2c(Cl)nnn2CCCCl)C=CCCC1$ 

#### **Products:**

1. Clc1nnn2c1C1(C=CCCC1)OCCC2

 ${\bf Typical\ conditions:}\ {\rm K2CO3.acetone.heat}$ 

Protections: none

**Reference:** 10.1016/S0040-4020(01)90106-1 and 10.1021/acs.analchem.5b04461

and 10.3390/molecules 24091643

Retrosynthesis ID: 31010930

# 2.2.7 Kumada-Corriu reaction

#### Substrates:

- 1. Clc1nnn2c1C1(C=CCCC1)OCCC2
- 2. butylmagnesium bromide

#### **Products:**

# $1. \ \ CCCCc1nnn2c1C1(C=CCCC1)OCCC2$

 $\textbf{Typical conditions:} \ \mathrm{NMP.Pd}(\mathrm{OAc}) \\ 2.\mathrm{PCy3} \\$ 

Protections: none

**Reference:** DOI: 10.1002/1521-3773(20021104)41:21<4056::AID-

ANIE4056>3.0.CO;2-8